



PVC STOP PROFILE J12 WITH TAPE ETIX 3831 (12,5mm)

The stop beads are designed for the precise finishing of plasterboard in ceiling or wall structures. They ensure a durable and aesthetically pleasing connection to adjacent structures made from different building materials. These beads are used in the installation of plasterboard to secure a firm connection between the boards or with adjacent structures.

Stop Profile	Width (mm)	PE Foam Tape Width (mm)	Length (m)	Packaging (pc)
ETIX 3831	12,5 mm	8	3,0	50

ADVANTAGES

- Provides an aesthetically pleasing board connection
- Protects the boards from mechanical damage
- The profile edges can cover minor damage to the board ends caused before installation
- Flexible PE foam tape allows for elastic connections with adjacent construction elements

INSTALLATION

Install the PVC stop profile with PE foam tape before plastering the wall. The installation surface must be smooth and even. Apply a layer of plaster to the outer surface, then press the PVC stop profile with PE foam tape into the plaster. Gradually cover the bead with plaster until a seamless surface with the wall is achieved.

MATERIAL

PVC, Polyethylene Foam Tape.

STORAGE

Store in a horizontal position. Keep in a dry place and protect from moisture and mechanical stress.